

Model 4200 Manual Ratchet **Thread**er **Instructions** & **Di**e List

To Insert New Dies:

- Place die head in upright position as shown in Figure A.
- 2 Remove screws (#4) in cover plate (#2), lift off cover plate and remove old dies.
- Insert new dies into position in die head with throat down as shown in Figure B. Be sure that each die number (#6-Figure B) agrees with the die head slot number (#3-Figure A) in which it is placed.
- 4 Replace the cover (#2) engaging lugs in dies. Replace screws (#4) and tighten screws lightly.
- Slide die head on already threaded nipple or pipe (#5) and turn until dies engage in thread (see Figure C). This assures that each die is seated properly against the lug on the cover this is required for accurate threading.
- 6 Tighten screws (#4) securely.

12R Style Dies NPT	12R Style Dies NPSM	12R Style Head with Dies - NPT	12R Style Head with Dies - NPSM
837810 1/8"	837945 1/8"	837375 1/8"	837555 1/8"
837815 1/4"	837950 1/4"	837380 1/4"	837560 1/4"
837820 3/8"	837955 3/8"	837385 3/8"	837565 3/8"
837825 1/2"	837960 1/2"	837390 1/2"	837570 1/2"
837830 3/4"	837965 3/4"	837395 3/4"	837575 3/4"
837835 1"	837970 1"	837400 1"	837580 1"
837840 1-1/4"	837975 1-1/4"	837405 1-1/4"	837585 1-1/4"
837845 1-1/2"	837980 1-1/2"	837410 1-1/2"	837590 1-1/2"
837850 2"	837985 2"	837415 2"	837595 2"






Figure B
New Dies Throat Down
(Match Numbers)





Figure C Seat Dies – Required! (See Step 5 Above)





Wheeler Manufacturing Div. REX Intl USA Inc.
P.O. Box 688 * 3744 Jefferson Road * Ashtabula, OH 44005
Tel: 800-321-7950 or 440-998-2788 * Fax: 440-992-2925 www.wheelerrex.com

